

	YK400	YK550	-	-	YK650	YK800	YK900	YK1100	YK1300
	GX120	GX160	GXV160	GCV160	GX200	GX240	GX270	GX340	GX390
Air Cleaner Element	30-48	30-04	30-08	-	30-04	30-05	30-05	30-06	30-06
Air Cleaner Assy	-	30-01	-	-	-	30-02	30-02	30-03	30-03
Air Cleaner Pre Filter	-	30-10	30-11	-	30-11	30-12	30-12	30-13	30-13
Camshaft	36-10	36-11	36-13	36-14	36-12	36-15	36-16	36-17	36-18
Carburetor (Engine Purpose)	49-08	49-10	49-18	49-60	49-11	49-12	49-13	49-14	49-15
Carburetor (Generator Purpose)	-	49-96	-	-	49-97	49-99	49-99	49-69	49-71
Carburetor Repair Kit	49-01	49-02	49-07	-	49-02	49-03	49-03	49-04	49-04
Connecting Rod	36-20	36-21	36-23	36-24	36-22	36-25	36-25	36-26	36-26
Cooling Fan	01-08	01-09	01-09	-	01-09	01-10	01-10	01-35	01-35
Crankcase & Oil Pan Assy	36-116	36-117	36-133	36-134	36-117	36-118	36-118	36-119	36-119
Crankshaft (Standard Shaft)	36-01Q	36-02Q	36-04Q	36-05	36-03Q	36-06Q	36-07Q	36-08Q	36-09Q
Cylinder Barrel	36-44	36-45	36-216	36-123	36-47	36-48	36-49	36-50	36-51
Cylinder Barrel Assy.	99-01	99-02	99-15 (Snapper)	99-18	99-03	99-04	99-05	99-06	99-07
Cylinder Head Assy.	99-08	99-09	99-16 (Honda)	-	99-10	99-11	99-12	99-13	99-14
Cylinder Head Gasket	50-01	50-02	50-05	50-24	50-04	50-06	50-07	50-08	50-09
Cylinder Head	36-36	36-37	36-121	-	36-39	36-40	36-40	36-42	36-42
Dip Stick	07-15	07-15	07-17	07-83	07-15	07-15	07-16	07-16	07-16
Fan Cover	01-04	01-06	-	-	01-33	01-07	01-07	01-34	01-34
Flywheel	01-36	01-37	01-39	01-64	01-38	01-59	01-59	01-54	01-54
Fuel Bulk Hose	07-04	07-04	07-43	-	07-04	07-19	07-19	07-19	07-19
Fuel Filter w/Holder	07-10	07-10	-	-	07-10	07-10	07-10	07-10	07-10
Fuel Tank Assy	07-05	07-06	07-39	07-40	07-06	07-07	07-07	07-08	07-08
Fuel Tank Joint	07-50	07-50	-	-	07-50	07-50	07-50	07-50	07-50
Gas Cap	07-11	07-11	07-12	07-13	07-11	07-11	07-11	07-11	07-11
Gasket Kit	50-10	50-11	50-14	-	50-13	50-15	50-16	50-17	50-18
Governor Gear	36-92	36-92	36-96	-	36-93	36-94	36-94	36-95	36-95
Governor Slider	36-97	36-97	36-97	-	36-97	36-97	36-97	36-97	36-97
Head Cover Component	01-01	01-01	-	01-11	01-01	01-02	01-02	01-02	01-02

	YK400	YK550	-	-	YK650	YK800	YK900	YK1100	YK1300
	GX120	GX160	GXV160	GCV160	GX200	GX240	GX270	GX340	GX390
Ignition Coil Assy	33-04	33-04	33-03	33-10	33-04	33-05	33-05	33-05	33-06
Muffler	-	35-08	35-09	35-32	-	35-30	35-30	35-10	35-10
Muffler Deflector	35-25	35-25	-	-	-	35-26	35-26	35-26	35-26
Muffler Gasket	35-22	35-22	35-48	35-46	35-22	35-47	35-47	35-47	35-47
Noise Suppressor	33-15	33-15	33-16	-	33-15	33-15	33-15	33-15	33-15
Oil Alert Unit	33-14	33-14	-	-	33-14	33-21	33-21	33-22	33-22
Oil Filler Cap	07-18	07-18	-	-	07-18	07-18	07-57	07-57	07-57
Oil Level Switch	33-13	33-13	-	-	33-13	33-19	33-19	33-20	33-20
Piston Assy	36-27	36-28	36-30	36-31	36-29	36-32	36-33	36-34	36-35
Piston Ring	36-52	36-53	36-56	36-57	36-55	36-59	36-60	36-61	36-62
Push Rod	36-79	36-80	36-80	-	36-80	36-84	36-84	36-85	36-85
Recoil Assy	31-01	31-01	31-07	31-55	31-01	31-02	31-02	31-03	31-03
Recoil Starter Pulley	43-04	43-04	43-07	43-29	-	43-05	43-05	43-06	43-06
Recoil Starter Ratchet Assy	31-15	31-15	31-17	31-58	31-15	-	-	31-16	31-16
Recoil Starter Springs	43-02	43-02	43-11	-	43-02	43-03	43-03	43-03	43-03
Rocket Arm Assy	36-73	36-73	36-73	36-137	36-73	36-74	36-74	36-74	36-74
Spark Arrestor	35-16	35-16	-	-	-	35-17	35-17	35-19	35-19
Spark Plug	33-41	33-41	77-20	77-20	33-41	33-42	33-42	33-11	33-11
Start/Stop Switch	33-12	33-12	-	-	33-12	33-12	33-12	33-12	33-12
Starter Motor	-	33-83	-	-	33-83	33-48	33-48	33-49	33-49
Valve Assy	36-63	36-64	36-65	36-66	36-64	36-67	36-67	36-68	36-68
Valve Lifter	36-86	36-86	36-88	-	36-87	36-89	36-89	36-89	36-89
Valve Retainer	36-75	36-75	36-75	-	36-75	36-74	36-74	36-74	36-74
Valve Rotator	36-90	36-90	-	-	36-90	36-91	36-89	36-89	36-89
Valve Springs	36-69	36-69	36-70	36-71	36-69	36-72	36-72	36-72	36-72