


▲  
24

Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
1	1	61370016AR	Guard			Grigio; Grey	
2	3	3891037R	Screw				
3	6	3891047R	Screw				
4	6	3891009R	Screw				
5	1	58070143R	Cover				
6	1	61370276	Screen + Gasket				
7	1	094600126	Tube				
8	1	61370015R	Complete muffler				
9	1	61370143R	Deflector				
10	1	3055112	Spark plug				
11	1	58070011R	Gasket				
12	2	58070166R	Ring				
13	1	61370085R	Crankcase assy				
14	2	61370208R	Piston ring				
15	1	61370252	Piston assy Ø32				
16	1	61370253	Complete cylinder Ø32				
17	1	58070045R	Shaft				
18	1	61370254	Set roller cage and washer				
19	2	3034007R	Bearing				
20	3	3891051R	Screw				
20	1	58070022R	Gasket				
21	5	61280044R	Plug				
22	2	3050042R	Ring				
23	2	3025018R	Ring				
24	1	61370255	Gasket set				


# Brushcutter - Starter Assy and fuel tank



# Brushcutter - Starter assy and fuel tank



Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
1	1	2501002R	Ignition coil				
2	1	50050127	Spring				
3	2	50160218	Spacer				
4	2	3891020R	Screw				
5	1	61370059R	Cable				
6	7	3891043R	Screw				
7	7	3893060R	Screw				
8	1	61370082R	Handle				
9	1	61370256	Flange kit				
10	1	61370024R	Rope				
11	1	61070036R	Spring				
12	1	61370022R	Pulle				
13	1	61240059R	Spring				
14	1	61370023R	Sprocket				
15	1	50160024	Screw				
16	1	61370230R	Starter assy			Rosso; Red	
17	2	61370014R	Pawl				
18	2	61070039R	Spring				
19	1	61370013R	Clutch driver				
20	1	3064034	Washer				
21	1	58070133R	Flywheel				
22	1	004400959R	Nut				
23	1	61070090R	Spring				
24	1	61070091AR	Clutch				
25	1	61370257	Kit pin + Belleville washer + spacer ring				
26	5	3893009R	Screw				
27	1	61370031R	Flange				
28	1	4098377	Band				
29	1	61370083R	Clutch drum				
30	1	61070006R	Gasket				
31	1	61370033AR	Cover				
32	1	61250249R	Adjust. pin				
33	1	3024010R	Ring				
34	1	61372003R	Tank cap				
35	1	61070011AR	Breather valve				
36	1	3073001R	Breather fuel pipe				
37	1	4161211	Bush				
38	1	61370038R	Tube				
39	1	61110162A	Bushing				
40	1	094600450R	Fuel filter				
41	1	61370184R	Cover with fuel tank			Rosso; Red	
42	1	61370030R	Sleeve				
43	1	61370029R	Adaptor				
44	1	61370028R	Adaptor				
45	2	3914003R	Nut				
46	2	3891050R	Screw				



## Brushcutter - Air filter



Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
1	1	58070025AR	Gasket				
2	1	61370001R	Insulator				
3	2	3891046R	Screw				
4	1	2318265R	Carburetor				
5	1	56570058R	Gasket				
6	1	61370160R	Air filter				
7	1	61370258	Filter cover kit			Grigio; Grey	
8	1	61370008R	Knob				
9	1	3891063R	Screw				
10	1	61372008R	Filter support			Grigio; Grey	
11	1	2318817R	Air purge				
12	1	61370255	Gasket set				
13	1	61200196R	Gasket				
14	1	3073002R	Tube				
15	1	61370036R	Tube				




## Brushcutter - Transmission



Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
1	1	4162042A	Handle				
2	1	3915006	Nut				
3	1	3916006R	Washer				
4	5	3893060R	Screw				
5	1	61370043R	Lever				
6	1	61370260	Lever group				
7	1	61370044AR	Throttle lever				
8	1	3906053	Screw				
9	1	61370220AR	Throttle cable				
10	1	61370032R	Cable				
11	1	61370148R	Tube Ø22				
12	1	61370261	Handle kit				
13	1	61370226R	Drive shaft				
14	1	3025017R	Ring				
15	2	3035004R	Bearing				
16	1	3914003R	Nut				
17	1	3891051R	Screw				
18	1	61370123R	Pin				
19	1	61370124R	Flange				
20	1	61370145R	Hub				
21	1	3893016R	Screw				
22	1	61370161AR	Blade				
23	4	61150012R	Spacer				
24	4	3891046R	Screw				
25	1	61370314	Guard kit				
26	1	63119001	Compl. nylon head				
27	1	61370227R	Insert				
28	1	61370214R	Tool kit				
29	1	61370293	Labels kit				





■ 4 — KIT RIPARAZIONE  
REPAIR KIT



Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
1	1	2318265R	Carburetor				Gaznik
2	2	2318837	Adjust. screw				Sruba
3	2	2318867	Clamp				Korek
4	1	2318671	Repair kit				Zestaw naprawczy

