


E04

Tanaka

TC-47


Serial No.

E04-01 CYLINDER/PISTON/CRANK SHAFT




REF. NUMBER	PARTS NUMBER	DESCRIPTION	Q'TY	SERIAL NUMBER
E04-01 CYLINDER/PISTON/CRANK SHAFT				
006	668-7479	SPARK PLUG CAP ASS'Y	1	
007	668-8336	SPARK PLUG RUBBER COVE	1	
008	668-5085	SPARK PLUG BPM6A	1	
011	668-5470	CYLINDER SET	1	
012	668-4586	HEX.HOLE BOLT M5X18/S	4	
014	668-5738	CYLINDER GASKET	1	
015	668-6126	PISTON RING	2	
016	668-5887	PISTON SET	1	
017	668-6019	PISTON PIN 10X35	1	
018	668-6026	PISTON PIN CIRCLIP	2	
020	668-5993	PISTON PIN COLLAR	2	
021	668-6190	CRANK SHAFT COMP.	1	
022	669-5602	NEEDLE BEARING, 2X8.8	1	
031	668-6457	WOOD-RUFF KEY 3X13X5	1	

E04-02 CRANK CASE




REF. NUMBER	PARTS NUMBER	DESCRIPTION	Q'TY	SERIAL NUMBER
E04-02 CRANK CASE				
019	669-5139	SMALL NUT 10	1	
023	669-3302	STARTER PAWL	1	
024	669-3345	STARTER PAWL SPRING	1	
025	669-3395	STARTER PULLEY	1	
026	668-6553	CRANK CASE ASS'Y	1	
027	668-6713	CRANK CASE GASKET	1	
028	669-5635	OIL SEAL 15257	2	
029	669-5557	BALL BEARING #6202, 35MM/	2	
030	668-6463	CRANK SHAFT WASHER 15.2	2	
032	669-8030	CRANK SHAFT SHIM 0.05	V	
032	668-6470	CRANK SHAFT SHIM 0.10	V	
032	668-6471	CRANK SHAFT SHIM 0.15	V	
032	668-6472	CRANK SHAFT SHIM 0.20	V	
032	668-6473	CRANK SHAFT SHIM 0.30	V	
033	668-4683	STOP RING E-5	1	
036	669-5367	SCREW 6X45/S	2	
038	669-5364	SCREW 6X30/S	2	
046	668-4872	LOCK NUT M6	1	
047	669-4043	OUTER RECEIVER	1	
051	668-7371	MAGNET ROTOR COMP.	1	
052	669-5185	SMALL WASHER 10	1	
054	669-5138	NUT 10	1	
055	668-7649	IGNITION COIL COMP.	1	
056	669-5419	SCREW 5X18/WS	2	
063	668-8004	CORD CLAMP COMP.	2	
066	668-6976	FAN CASE POLISH	1	
067	669-5361	SCREW 6X20/S	4	
068	668-8055	PRIMARY CORD GROMMET	1	
069	668-8049	PRIMARY CORD GROMMET	1	
070	668-7868	STOP CORD 240L	1	

E04-03 ENGIN-1




REF. NUMBER	PARTS NUMBER	DESCRIPTION	Q'TY	SERIAL NUMBER
E04-03	ENGINE-1			
027	669-2225	FUEL TANK CUSHION RUBBER	2	
031	668-9883	INLET MANIFOLD GASKET	1	
032	668-9950	CARB. INSULATOR SET	1	
033	668-9826	CARBURETOR GASKET	1	
045	669-0467	CARBURETOR SET HDA97	1	
049	669-5423	SCREW 5X24WS	2	
051	669-1004	CHOKE LEVER	1	
052	668-5267	FUEL PIPE 2.5X4X90	2	
053	669-5138	NUT 10	1	
054	669-5235	INNER TOOTHED WASHER 10	1	
055	669-0080	PRIMING PUMP COMP.	1	
063	668-8166	FUEL PIPE ASS'Y 3X5X180	1	
064	668-4619	CLIP,6.3 DIA.	1	
065	669-2273	PUMP FILTER BODY ASS'Y	1	
066	669-1526	FUEL TANK, WHITE	1	
068	668-4627	RETURN GROMMET	1	
070	669-1763	TANK CAP D ASS'Y, BLACK	1	
071	669-3883	THROTTLE WIRE 2070+115	1	
076	669-1927	TANK HOLDING BAND	1	
077	669-2193	CUSHION RUBBER	1	
078	669-5386	SCREW 5X16/PS	2	
096	668-4625	TANK CAP CHAIN	1	

E04-04 ENGINE-2




REF. NUMBER	PARTS NUMBER	DESCRIPTION	Q'TY	SERIAL NUMBER
E04-04 ENGINE-2				
001	669-2777	MUFFLER PROTECTOR	1	
002	669-5383	SCREW 5X12/PS	1	
003	668-4667	HEX.HOLE BOLT M5X12/S	1	
004	668-4918	WASHER M5	1	
005	669-5088	HEX. HOLE BUTTON SCREW	2	
006	668-4639	WASHER 6	2	
007	669-2463	MUFFLER SET	1	
009	669-2883	MUFFLER SPECIAL GASKET	1	
010	669-2651	TAIL PIPE SET, SPARE	1	
011	669-5325	SCREW 4X8/S	2	
014	669-2741	MUFFLER GASKET	1	
016	668-7242	HEAT SHIELD	1	
023	669-5389	SCREW 5X18/PS	2	
024	669-5395	SCREW 5X25PS	2	
025	669-2205	TANK BRACKET	1	
026	669-2227	FUEL TANK CUSHION RUBBER	2	
081	668-9645	CLUTCH WASHER B	2	
082	668-8615	CLUTCH ARM	2	
083	668-9429	CLUTCH SPRING	1	
084	669-5203	WAVE WASHER 10	2	
085	668-9628	CLUTCH STEP BOLT	2	

E04-05 AIR CLEANER




REF. NUMBER	PARTS NUMBER	DESCRIPTION	Q'TY	SERIAL NUMBER
E04-05 AIR CLEANER				
036	669-0106	CLEANER BODY	1	
037	669-2244	COLLAR 5.8	2	
038	669-0848	BLOW OVER CHECK BOARD	1	
039	669-0365	CLEANER SPONGE	1	
041	669-0148	CLEANER CAP	1	
042	669-0383	COVER FIXING BOLT	1	
043	669-4916	SCREW 5X60	2	
044	668-4662	S.WASHER 5	2	

E04-06 RECOIL STARTER




REF. NUMBER	PARTS NUMBER	DESCRIPTION	Q'TY	SERIAL NUMBER
E04-06 RECOIL STARTER				
000	669-2970	RECOIL STARTER BODY ASS'Y	1	
001	669-3025	RECOIL STARTER BODY COM	1	
002	669-3007	STARTER ROPE REEL	1	
003	669-3114	RECOIL SPRING	1	
009	669-3165	STARTER ROPE	1	
012	669-3607	STARTER HANDLE CAP	1	
014	669-3232	STARTER HANDLE	1	
017	669-3634	SET SCREW	1	

E04-07 CARBURETOR



REF. NUMBER	PARTS NUMBER	DESCRIPTION	Q'TY	SERIAL NUMBER
E04-07 CARBURETOR				
001	668-5210	SCREW	1	
002	669-1420	PUMP BODY	1	
003	669-1455	PUMP GASKET	1	
004	669-1446	PUMP DIAPHRAGM	1	
005	668-4700	INLET SCREEN	1	
017	669-0766	IDLE ADJUST SPRING	1	
018	669-0736	IDLE ADJUST SCREW	1	
019	669-2049	ADJUST SPRING	2	
020	669-0715	LOW ADJUST SCREW	1	
021	669-0692	HIGH ADJUST SCREW	1	
022	668-5215	NEEDLE VALVE	1	
023	669-0871	VALVE SPRING	1	
024	669-0819	CONTROL LEVER	1	
025	668-5219	HINGE PIN	1	
026	668-5218	HINGE PIN SET SCREW	1	
027	669-0840	DIAPHRAGM GASKET	1	
028	669-0829	METERING DIAPHRAGM COM	1	
029	669-0434	AIR PURGE COMP.	1	
030	669-0860	DIAPHRAGM COVER	1	
031	669-1310	SET SCREW	4	
000	669-2186	CARB. REPAIR KIT, K12-HDA	1	
000	669-2196	GASKET/DIA. KIT, D11HDA	1	

E04-08 LABELS/TOOLS



REF. NUMBER	PARTS NUMBER	DESCRIPTION	Q'TY	SERIAL NUMBER
E04-08 LABELS/TOOLS				
001	N/A	Not Available	1	
031	668-4764	BOX WRENCH (HEX. SOCKET	1	